
No Drill Application STEP-by-STEP

Step 1. Surface Cleaning

Clean surface area that is to be covered by spoiler thoroughly, with Isopropyl Alcohol.

Step 2. Test Fitting the Unit

Before removing the tape backing, test fit spoiler in order to get comfortable with the placement. You can mark the position with a grease pen or masking tape for a perfect fit.

Step 3. Preparation

Peel back the corner of the red liner on the 3M tape and remove all pieces, avoid touching exposed tape.

Step 4. Installation

Gently press spoiler into place on the deck lid, hatch or rear glass. Once satisfied with placement, firmly press down on spoiler to ensure cohesion along entire vehicle surface. Continue to apply pressure or use masking tape to keep unit from lifting.

Helpful Tips

Adhesive silicones and/or adhesion promoters are often used in conjunction with provided 3M tape for long lasting durability. For best results installation should be conducted in temperatures above 72. Refer to tape manufacturers recommendations for full details. Do Not clean, wash, wax or drive for 12 hours after installation. Elite Spoilers is not responsible for no drill attachment durability.